



Connecting the Active Emitter to the DS8000 Network Sound Masking Processor




1.

Connect your plenum rated 18 AWG 2 conductor cable to one of the included terminal block connectors.




2.

Plug the terminal block connector into the Active Emitter.



3.

Connect the other end of the cable to one of the terminal block connectors that ships with the DS8000.



4.

Plug the terminal block connector into the DS8000. Be sure to maintain the polarity from the connector attached to the Active Emitter and the DS8000.

WHEN CONNECTED TO A DS8000:

1. Only connect a single Qt Active Emitter per DS8000 output.
2. The RJ45 Input and Output jacks are inoperable.
3. The attenuation DIP switches are disabled
4. External Qt Power Supply and Qt Power Injectors are not required.